

Assembly Instruction For 13501

- 1. Thread the nipple into the coupler then secure by hex nut.
- 2.Attached the tube, tube cover and glass stator in order like the drawing on the nipple then secure by hex nut.
- 3.Attached the glass, cap on the nipple then secure by hex nut.
- 4. Attached the cap on the nipple then secure by finial.

