

Assembly Instruction For 21304

- 1. Spread the arms evenly.
- 2. Turn the nipple into the coupler.
- 3. Attach the cover on the nipple then secure by the loop.
- 4. The nipple 1 through the hole of the metal sheet .
- 5. Attach the cover 1 to the nipple 1 then secure by the finial.
- 6.Attach the glass on the sockets then secure by the socket rings.

