

MAXIM Assembly Instruction For 21347

1. Secured ball tips(E) by tube (D).
2. Secured tube(D) by tube(C).
3. Secured tube(C) by tube(C1).
4. Secured tube(C1) by tube(C2).
5. Secured tube(C2) by ball tips(B).
6. Place Ceiling pan(A) into tube(B).
7. Secured coupler(G) by nipple(I), then Secured nipple(I) by hexnut(H).
8. Place glass shade(J) into metal(F) ;
9. Place cap(K) into nipple(I) ; then secured nipple(I) by nexnut(H).
10. Secured nipple(I) by ball tips(L).

