

Assembly Instruction For 93505

- 1. Screw the nipple to the coupler.
- 2.Attached the poly part on the nipple the secure by loop.
- 3.Attached the glass on the socket then secure by socket ring.

