

ASSEMBLY INSTRUCTIONS FOR YOUR

Jonathan Adler

PARKER PENDANT SCONCE

IMPORTANT SAFETY INSTRUCTIONS:

- * These instructions are provided for your safety. It is important that they are read completely before beginning installation of fixture.*
- * WE STRONGLY RECOMMEND INSTALLATION BY LICENSED ELECTRICIAN*
- * Turn off power at switch before replacing bulb, making sure fixture has had sufficient time to cool down.*
- * If any special control devices are used with this fixture, follow the instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.*
- * SHUT OFF MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION*

ASSEMBLY INSTRUCTIONS:

1. Remove all parts carefully from the box.
2. Remove mounting plate (A) from backplate (C) by removing backplate screws (D).
3. Affix mounting plate (A) to wall outlet box with mounting plate screws (B) provided. Pull wires through center hole of plate (A).
4. Lift backplate (C) to mounting plate (A). Make proper electrical connections noted in steps 5 - 7. A LICENSED ELECTRICIAN IS RECOMMENDED.
5. Attach ground wire from fixture to ground wire from fixture (green, copper or silver in color) to ground wire from wall outlet box.
6. Attach hot wire from fixture (black in color, or smooth side of wire) to hot wire from wall outlet box. Fasten wires together with wire nut (K) and tightly wrap connection with electrical tape.
7. Attach neutral wire from fixture (white in color, or ribbed side of wire) to neutral wire from wall outlet box. Fasten wires together with wire nut (K) and tightly wrap connection with electrical tape.
8. Gently push wires back into wall outlet box.
9. Slide backplate (C) over mounting plate (A) and align holes in mounting plate (A) with holes in backplate (C). Thread backplate screws (D) into holes to secure fixture to wall.
10. Carefully slide glass shade (G) up over socket (F). Align holes in glass shade (G) with holes in socket housing (E). Insert threaded ends of shade support arms (H) through holes in glass shade (G), and into threaded holes in socket housing (E). Turn shade arms (H) in clockwise motion until hand tight.
11. Remove threaded nuts (J) from shade support arms (H) and set aside. Caution, make sure not to unthread shade support arms (I) from socket housing (E) when removing threaded nuts (J) from shade support arms (H).
12. Carefully slide metal shade (I) up over glass shade (M). Align holes in metal shade (N) with exposed sections of shade support arms (I). Insert nuts (J) through holes in metal shade (I) and into ends of shade support arms (I). Turn threaded nuts (J) in clockwise motion until hand tight.
13. Insert one (1) 60W MAX. Type B, medium base bulb into socket (F).
14. To clean, wipe fixture with soft cloth. Do not use any chemical or abrasive cleaners as they will damage the finish.

